



Disclaimer: This diagram should only be used as an aid to show the general layout of drive system components. It is not a replacement for the official handbook and documentation that are provided with a Fischer Panda electric drive system. The information here is correct at the time of publication and may be subject to change without prior notification.